


# AHKD SERIES ELECTRIC RESISTANCE HEAT KITS INSTALLATION & OPERATING INSTRUCTIONS



Made in the USA by:  
Goodman Manufacturing Company, L.P.  
2550 North Loop West, Suite 400  
Houston, TN 77092  
[www.goodmanmfg.com](http://www.goodmanmfg.com)

# Contents

---

Introduction		Attaching the Heat Kit .....	6
Product Description .....	2	Electrical Connections	
Checking Product Received .....	2	Supply Voltage .....	7
Before Beginning Installation .....	2	Low Voltage .....	7
Ordering Parts .....	2	Single/Two-Stage Heat .....	7
Important Safety Instructions		Wiring Diagrams	
Recognize Safety Symbols, Words and Labels .....	3	AHKD15-3 .....	8
Model Identification		AHKD20-3 & AHDK30-3 .....	8
Heating kW .....	4	AHKD15-4 .....	9
Temperature Rise		AHKD20 & AHKD30-4 .....	9
AR090 & AR120 .....	4	Parts List .....	10
Electical Supply Wire & MOP			
Maximum/Minimum Supply Voltage .....	5		
Voltage Balance .....	5		
MCA .....	5		
MOP .....	6		

## Introduction

---

### Product Description

The AHKD series of electric heat kits is an accessory designed for installation with the Goodman AR090 or AR120 Airhandler **ONLY**. **INSTALLATIONS WITH OTHER AIRHANDLERS IS NOT PERMITTED**. For installation guidelines of the AR090 or AR120, refer to the instructions which accompany the air handler, IO-227(Installation & Operating Instructions).

The AHKD provides supplemental electric heat for the AR90/120. The assembly is to be installed directly to the outlet of the AR090/120 and is not to be used as an independent duct heater.

The AHKD20 and AHKD30 heat kits have two stages. A two stage room thermostat determines the staging by room temperature.

The heat kit's control panel is "self contained" and is equipped with all of the safety circuit/limits required per UL1995. The heat kit employs a terminal block for installation of the high voltage wires used by both the heat kit and the airhandler (single point wiring).

### Checking Product Received

- Upon receiving the unit, inspect it for damage from shipment. Claims for damage, either shipping or concealed, should be filed immediately with the shipping company. Check the unit model number, specifications, electrical characteristics, and accessories to determine if they are correct. In the event an incorrect unit is shipped, it must be returned to the supplier and must NOT be installed. The manufacturer assumes no responsibility for the installation of incorrectly shipped units.

### Before Beginning Installation

- Carefully read all instructions for the installation prior to installing unit. Make sure each step or procedure is understood and any special considerations are taken into account before starting installation.
- Assemble all tools, hardware and supplies needed to complete the installation. Some items may need to be purchased locally. Make sure everything needed to install AHKD Electric Resistance Heat Kits is on hand before starting.

### Ordering Parts

- When reporting shortages or damages, or ordering repair parts, give the complete unit model and serial numbers as stamped on the unit's nameplate. Order parts through your local distributor.

# Important Safety Instructions

## Recognize Safety Symbols, Words, and Labels

The following symbols and labels are used throughout this manual to indicate immediate or potential hazards. It is owner's responsibility to read and comply with all safety information and instructions accompanying these symbols. Failure to heed safety information increases the risk of serious personal injury or death, property damage and/or product damage.



**Danger** - Immediate hazards which **WILL** result in severe personal injury or death.



**Warning** - Hazards or unsafe practices which **COULD** result in severe personal injury or death.



**Caution** - Hazards or unsafe practices, which **COULD** result in minor or moderate personal injury, product damage, or property damage.



Before servicing or installing this equipment, the electrical power to this unit **MUST** be in the "OFF" position.

**IMPORTANT NOTE:**

More than one disconnect may exist. Failure to observe this warning may result in an electrical shock that could cause serious personal injury or death.



**ONLY TRAINED AND QUALIFIED PERSONNEL ARE PERMITTED TO INSTALL OR SERVICE THIS EQUIPMENT.** Observe ALL warnings contained in this manual and labels/tags attached to the equipment.

When installing or servicing this equipment safety clothing including hand and eye protection is strongly advised. If installing this equipment in an area that has special safety requirements (hard hats etc.) observe these requirements.

Read these instructions before performing this installation or servicing this unit. All installations must be in accordance with all national, state, or local building codes.



This installation **must** have an uninterrupted, unbroken electrical ground to minimize the possibility of personnel injury if an electrical fault should occur. The electrical ground circuit may consist of an appropriately sized electrical wire connecting the ground lug in the unit control box wire to the building electrical service panel. Other methods of grounding are permitted if performed in accordance with the "National Electric Code" (NEC)/ "American National Standards Institute" (ANSI)/ "National Fire Protection Association" (NFPA) 70 and local/state codes. In Canada, electrical grounding is to be in accordance with the Canadian Electric Code CSA C22.1. Failure to observe this warning can result in electrical shock that could cause serious personal injury or death.

# Model Identification



The electrical characteristics of the airhandler, the electric heat kit, and the building power supply must agree.

Use the following table and the product's Series and Rating plate to determine the heating kW and electrical characteristics.

Table 1.

AHKD Model Number	Nominal kW	Electrical Characteristics	Stages
AHKD15-3	15	208-230/3/60	1
AHKD15-4	15	460/3/60	1
AHKD20-3	20	208-230/3/60	2
AHKD20-4	20	460/3/60	2
AHKD30-3	30	208-230/3/60	2
AHKD30-4	30	460/3/60	2

For all supply voltages, use the correction factors in Tables 2 & 3, multiplied by kW and (or) temperature rise to have corrected results.

Table 2.

KW Correction Factors (-3 models)					
Supply Voltage	240	230	220	210	208
Correction Factor	1.0	0.92	0.84	0.77	0.75

Table 3.

KW Correction Factors (-4 models)					
Supply Voltage	480	460	440	415	380
Correction Factor	1.0	0.92	0.84	0.75	0.63

# Temperature Rise

The heating mode temperature rise is dependent upon the system airflow, the supply voltage, and the heat kit size (kW) selected. Use Tables 4 & 5 to determine the temperature rise (°F):

Table 4.

AR090 Temperature Rise Table (Degrees F)

Airhandler	Heat Kit KW	CFM	Supply Voltage		
			208	240	480
AR090	15	2800	14	19	19
		2900	14	18	18
		3000	13	18	18
		3100	13	17	17
		3200	12	17	17
	20	2800	19	25	25
		2900	18	24	24
		3000	18	24	24
		3100	17	23	23
		3200	17	22	22
	30	2800	28	38	38
		2900	27	37	37
		3000	27	35	35
		3100	26	34	34
		3200	25	33	33

Table 5.

AR120 Temperature Rise Table (Degrees F)

Airhandler	Heat Kit KW	CFM	Supply Voltage			
			208	240	480	
AR120	15	3800	10	14	14	
		3900	10	14	14	
		4000	10	13	13	
		4100	10	13	13	
		4200	9	13	13	
		3800	14	19	19	
	20	3900	14	18	18	
		4000	13	18	18	
		4100	13	17	17	
		4200	13	17	17	
		30	3800	21	28	28
			3900	20	27	27
	4000		20	27	27	
	4100		19	26	26	
	4200		19	25	25	

**Note:** Table 5 is calculated with both stages of electric heat engaged (2 stage heat systems). For systems using staged electric heat, divide the temperature rise from the table by 2 for 1<sup>st</sup> stage operation.

# Electrical Supply Wire and MOP



Before servicing or installing this equipment, the electrical power to this unit **MUST** be in the “OFF” position.

**IMPORTANT NOTE:**

More than one disconnect may exist. Failure to observe this warning may result in an electrical shock that could cause serious personal injury or death.



The unit **must** have an uninterrupted, unbroken electrical ground to minimize the possibility of personal injury if an electrical fault should occur. The electrical ground circuit may consist of an appropriately sized electrical wire connecting the ground lug in the unit control box wire to the building electrical service panel. Other methods of grounding are permitted if performed in accordance with the “National Electric Code” (NEC)/“American National Standards Institute” (ANSI)/“National Fire Protection Association” (NFPA) 70 and local/state codes. In Canada, electrical grounding is to be in accordance with the Canadian Electric Code CSA C22.1. Failure to observe this warning can result in electrical shock that could cause serious personal injury or death.



To avoid the risk of fire or equipment damages use only copper conductors



Inspection of the Building Electrical Service. This unit is designed for 3-phase operation. **DO NOT OPERATE ON A SINGLE PHASE POWER SUPPLY. SEE THE “WARNING” ABOVE.** Measure the power supply to the unit. The supply voltage **MUST** be in agreement with the unit nameplate power requirements and within the range shown in Table 6.

Table 6.

Nominal	Minimum Supply Voltage	Maximum Supply Voltage
208 – 230	187	253
460	414	506

Voltage Balance The supply voltage shall be unbalance (phase to phase) within 2%. To calculate the percentage of voltage unbalance use the following formula:

$$\text{Percentage Voltage Unbalance} = 100 \times \frac{\text{Max Voltage Deviation From Avg}}{\text{Average Voltage}}$$

*Example*

$$\begin{aligned} L1 - L2 &= 220 \text{ V} \\ L2 - L3 &= 216 \text{ V} \\ L1 - L3 &= 213 \text{ V} \end{aligned}$$

$$\begin{aligned} \text{Avg. Voltage} &= (220+216+213) / 3 \\ &= 649 / 3 \\ &= 216 \end{aligned}$$

$$\text{Max. Deviation from Avg.} = 220 - 216 = 4$$

$$\begin{aligned} \% \text{ Voltage Unbalance} &= 100 \times (4 / 216) \\ &= 400 / 216 \\ &= 1.8\% \end{aligned}$$

Determine Wire Size The selection of the appropriate supply wire size is important to the operation of the equipment. When selecting the wire size, the following are important elements of the decision:

- The wire size is adequately sized to carry the Minimum Circuit Ampacity (MCA). Refer to the NEC (USA) or CSA (Canada) for wire sizing. The unit MCA for the airhandler and the optional electric heat kit can be found on the equipment S&R plate and Table 7.

Table 7.

AIR	VOLTAGE	HEAT KIT	MCA
AR090	208 - 230	AHKD15-3	48.6
		AHKD20-3	63.0
		AHKD30-3	91.9
	460	AHKD15-4	24.3
		AHKD20-4	31.5
		AHKD30-4	46.0
AR120	208 - 230	AHKD15-3	49.4
		AHKD20-3	63.8
		AHKD30-3	92.7
	460	AHKD15-4	24.7
		AHKD20-4	31.9
		AHKD30-4	46.4

- The wire size is appropriately sized to allow for no more than a 2% voltage drop from the building breaker/fuse panel to the unit.
- Refer to the latest edition of the National Electric Code or in Canada the Canadian Electric Code when determining the correct wire size.

Table 8.

Table 8 shows the current carrying capabilities for copper conductors rated at 75°C with a 2% voltage drop.

Max. Allowable Length in Feet to Limit Voltage Drop to 2%								
Wire Size (AWG)	Min. Circuit Ampacity (MCA)							
	10	15	20	25	30	35	40	45
14	75	50	37	NR	NR	NR	NR	NR
12	118	79	59	47	NR	NR	NR	NR
10	188	125	95	75	63	54	NR	NR
8	301	201	150	120	100	86	75	68
6	471	314	235	188	157	134	118	110

Based on NEC 1996

### Maximum Overcurrent Protection (MOP)

Every installation must include an NEC (USA) or CEC (Canada) approved overcurrent protection device. Also check with local or state codes for any special regional requirements.


This protection can be in the form of fusing or HACR style circuit breakers. The following table can be used as a guide for selecting the MAXIMUM overcurrent device. This information is also stated on the equipment S&R plate. Note: fuses or circuit breakers are to be sized larger than the equipment MCA but not to exceed the MOP listed in Table 9.

Table 9.


AIR HANDLER	HEAT KIT	MOP
AR090	AHKD15-3	60
	AHKD20-3	70
AR120	AHKD30-3	100
	AHKD15-4	30
	AHKD20-4	35
	AHKD30-4	50

## Attaching the Heat Kit

1. Secure the high voltage and low voltage conduits to the heat kit electrical panel using the supplied plastic bushing nuts as shown in Figure 1.



2. Position the heat kit onto the airhandler at the air discharge end with the control box orientated toward the airhandler front. See Figure 2.




3. Route the two electrical conduits (attached in step 1.) through the panel on the airhandler. Secure the conduits to the airhandler panel with the supplied plastic bushing nuts.
4. Using the supplied 1/2" long #10 screws, attach the heat kit to the airhandler outlet panel. **Note:** Open the heat kit electrical panel door to obtain access to the three screws on that side.
5. Follow the "Electrical Connections" section of this manual for wiring details.

# Electrical Connections

**Supply Voltage** A single point supply voltage termination is provided in the heat kit control box.


The supply wire is to be routed through conduit from the service disconnect box to the heater kit. The heat kit is equipped with a knockout suitable for conduit. The supply voltage is to be installed on the terminal block located in the heater kit control box.

Route the air handler supply voltage and ground conductors through the 1/2" conduit that connects the heat kit to the airhandler. Attach the supply voltage wires to the airhandler contactor and the equipment ground to the airhandler ground lug. To assist with possible troubleshooting follow the wire color conventions indicated on the wiring diagram.



**Low Voltage.** The low voltage connection from the airhandler to the heat kit is provided through a multi-pin plug that connects to a mating plug in the airhandler. Route the heat kit low voltage harness through the 1 1/2" conduit to the airhandler control box and plug into the airhandler low voltage harness. **Note:** Low voltage from the room thermostat is terminated in the airhandler control box. Wiring options for the thermostat wiring are shown in the airhandler installation manual.

Figure 4.




Single Stage Heat - Single Stage Cooling where

- R - Red
- W - White
- G - Green
- BL - Blue


**Note:** Brown wire is not used and is to be taped.

Figure 5.




Two-Stage Heat - Single Stage Cooling where

- R - Red
- W - White
- BR - Brown
- G - Green
- BL - Blue





**Legend**  
 FR – Fan Relay  
 FU – Fuse  
 TB – Terminal Block  
 HC – Heater Contactor  
 HTR – Heater Element  
 PLS – Primary Limit Switch  
 SLS – Secondary Limit Switch




LADDER SCHEMATIC  
 MODEL NO. AHKD20-3 & AHKD30-3  
 20 & 30KW-240V.-3 PH.-60 HZ. "DELTA"





# Repair Parts



ITEM	PART NO.	DESCRIPTION	MANUFACTURER	MFR. PART NO.	AHKD					
					15-3	15-4	20-3	20-4	30-3	30-4
1	B1037600	HEATER ASM. 15KW-240V-3PH	HEATCRAFT	043-490532-01	1					
	B1037601	HEATER ASM. 20KW-240V-3PH	HEATCRAFT	043-490532-02			1			
	B1037602	HEATER ASM. 30KW-240V-3PH	HEATCRAFT	043-490532-03					1	
	B1037603	HEATER ASM. 15KW-480V-3PH	HEATCRAFT	043-490532-04		1				
	B1037604	HEATER ASM. 20KW-480V-3PH	HEATCRAFT	043-490532-05				1		
	B1037605	HEATER ASM. 30KW-480V-3PH	HEATCRAFT	043-490532-06						1
2	B1360338	CONTACTOR	WHITE ROGERS PRODUCT UNLIMITED	154-412221-5700PA 3100-30010191PL	1	1	1	1	1	1
3	B1170600	FUSE, 60A / 240V	BUSSMAN MFG. RELANCE FUSE GOULD-SHAWMUT LITTELFUSE	FRN-R60 ECNR-60 TR-60R FLNR60	3					6
	B1170601	FUSE, 40A / 240V	BUSSMAN MFG. LITTELFUSE	FRN-R40 FLNR40			6			
	B1170602	FUSE, 30A / 480V	BUSSMAN MFG. LITTELFUSE	JJS30 FLNR30		3				
	B1170603	FUSE, 35A / 480V	BUSSMAN MFG. LITTELFUSE	JJS35 JLLS35				3		
	B1170604	FUSE, 50A / 480V	BUSSMAN MFG. MARATHON	JJS50 JLLS50						3
4	B1170605	FUSE BLOCK, 3P/60A/250V	MARATHON BUSMAN MFG. GOULD-SHAWMUT	RF60A3B H25060-3C 20608	1		2			2
	B1170606	FUSE BLOCK, 3P/30A/600V	BUSSMAN MFG. MARATHON	T60030-3CR 6T30A3B		1				
	B1170607	FUSE BLOCK, 3P/60A/600V	BUSSMAN MFG. MARATHON	1B0078 4263806				1		1
5	B1368274	TERMINAL BLOCK	MARATHON BUSMAN MFG.	1423570 16220-3	1	1	1	1	1	1
6	B1370785	RELAY	AMERICAN ZETTLER	AZ2280-1A-24AEF(208)	1	1	1	1	1	1
7	B1370198	LIMIT, MANUAL RESET 160 °. F.	Klixon	20493L3-105	1	1	2	2	2	2
8	B1370199	LIMIT, AUTO RESET 140 °. F.	Thermo-Disc	60TX11-314463	1	1	1	1	1	1

**NOTE: SPECIFICATIONS AND PERFORMANCE DATA LISTED HEREIN ARE SUBJECT TO CHANGE WITHOUT NOTICE**

**Quality Makes the Difference!**

All of our systems are designed and manufactured with the same high quality standards regardless of size of efficiency. Our designs virtually eliminate the most frequent causes of product failure. They are simple to service and forgiving to operate. We use the highest quality materials and components available because if a part fails then the unit fails. Finally, every unit is run tested before it leaves the factory. That's why we know...

***There's No Better Quality.***

Visit our website at [www.goodmanmfg.com](http://www.goodmanmfg.com) for information on:

- Goodman Products
- Warranties
- Customer Services
- Parts
- Contractor Programs and Training
- Financing Options