

COPPER FLARE SEAL BONNETS



Unv Part	Part	Size	Box	Wt	List
B1-3	A 04737	3/16	25	0.001	2.68
B1-4	A 00414	1/4	100	0.001	0.61
B1-5	A 04935	5/16	50	0.004	3.57
B1-6	A 00415	3/8	100	0.004	0.71
B1-8	A 00416	1/2	100	0.007	1.21
B1-10	A 00485	5/8	20	0.010	1.02
B1-12	A 04738	3/4	25	0.015	2.68

COPPER FLARE GASKETS



Unv Part	Part	Size	Box	Wt	List
B2-4	A 00401	1/4	100	0.001	0.28
B2-5	A 04811	5/16	50	0.001	1.79
B2-6	A 00402	3/8	100	0.002	0.48
B2-8	A 00403	1/2	100	0.002	0.48
B2-10	A 05186	5/8	50	0.003	0.51
B2-12	A 04822	3/4	25	0.004	1.48

90° ELBOWS - HALF UNION



Flare to NPTFE

Unv Part	Part	Size	Box	Wt	List
E1-4A	A 00335	1/4 x 1/8	25	0.046	3.11
E1-4B	A 04890	1/4 x 1/4	25	0.055	3.11
E1-4C	A 04812	1/4 x 3/8	25	0.082	3.11
E1-6A	A 04937	3/8 x 1/8	25	0.080	5.56
E1-6B	A 00337	3/8 x 1/4	25	0.077	5.56
E1-6C	A 04889	3/8 x 3/8	25	0.108	5.56
E1-6D	A 04886	3/8 x 1/2	25	0.160	5.56
E1-8B	A 05044	1/2 x 1/4	10	0.135	6.99
E1-8C	A 00339	1/2 x 3/8	15	0.140	6.99
E1-8D	A 04887	1/2 x 1/2	15	0.180	6.99
E1-8E	A 05072	1/2 x 3/4	10	0.231	6.99
E1-10C	A 04856	5/8 x 3/8	10	0.225	11.73
E1-10D	A 04538	5/8 x 1/2	10	0.240	11.73
E1-10E	A 05054	5/8 x 3/4	10	0.255	11.73

90° ELBOWS - UNION



Flare to Flare

Unv Part	Part	Size	Box	Wt	List
E2-4	A 00147	1/4	25	0.074	6.43
E2-6	A 00146	3/8	25	0.095	6.43
E2-8	A 00145	1/2	15	0.150	6.43
E2-10	A 04539	5/8	10	0.250	11.22

90° ELBOWS

External Flare to NPTFI



Unv Part	Part	Size	Box	Wt	List
E3-4A	A 04630	1/4 x 1/8	25	0.050	3.11
E3-4B	A 05007	1/4 x 1/4	25	0.140	9.28

90° ELBOWS

External Flare to Internal Flare



Unv Part	Part	Size	Box	Wt	List
E4-44	A 04898	1/4 x 1/4	25	0.065	3.72
E4-66	A 08082	3/8 x 3/8	25	0.170	6.12

90° SOLDER ELBOWS - HALF UNION



Flare to Solder

Unv Part	Part	Size	Box	Wt	List
ES2-44	A 03449	1/4 x 1/4	25	0.035	3.11
ES2-66	A 03511	3/8 x 3/8	20	0.081	4.03
ES2-88	A 07851	1/2 x 1/2	10	0.120	8.21

90° SWIVEL ELBOWS



External Flare to Internal Flare

Unv Part	Part	Size	Box	Wt	List
ES4-44	A 15940	1/4 x 1/4	4	0.103	8.42
ES4-66	A 15941	3/8 x 3/8	4	0.133	9.44
ES4-88	A 15943	1/2 x 1/2	4	0.202	16.32

CONNECTOR - FUSIBLE PIPE PLUGS

NPTFE



Unv Part	Part	Size	Melting Temp	Box	Wt	List
FP-A	A 14058	1/8	283°F	10	0.022	7.34
FP-B	A 14059	1/4	283°F	15	0.035	9.44
FP-C	A 14060	3/8	283°F	15	0.084	11.53
FP-A	A 14017	1/8	210°F	10	0.024	7.34
FP-B	A 14018	1/4	210°F	15	0.054	9.44
FP-C	A 14021	3/8	210°F	15	0.090	11.53
FP-A	A 15214	1/8	168°F	10	0.024	7.34
FP-B	A 14019	1/4	168°F	15	0.054	9.44
FP-C	A 14022	3/8	168°F	15	0.095	11.53

CONNECTOR - HALF UNION

Flare to NPTFE



Unv Part	Part	Size	Melting Temp	Box	Wt	List
FU-4B	A 14062	1/4 x 1/4	283°F	10	0.047	9.44
FU-6C	A 14064	3/8 x 3/8	283°F	10	0.126	11.53
FU-4B	A 14023	1/4 x 1/4	210°F	10	0.057	9.44
FU-6C	A 14026	3/8 x 3/8	210°F	10	0.122	11.53
FU-4B	A 14024	1/4 x 1/4	168°F	10	0.048	9.44
FU-6C	A 14027	3/8 x 3/8	168°F	10	0.098	11.53

REFRIGERANT DRUM ADAPTERS



Unv Part	Part	Size	Box	Wt	List
K1-1	A 08073	1/4 x 3/4	10	0.159	5.76
K1-3	A 08274	3/8 x 3/4	10	0.187	5.76
K1-5	A 08276	1/2 x 3/4	10	0.194	12.90
K1-8	A 08166	1/4 x 1/2	10	0.148	16.32

NUT - LONG FORGED



Unv Part	Part	Size	Box	Wt	List
N4-4	A 00440	1/4	25	0.048	1.94
N4-6	A 00441	3/8	25	0.075	2.50
N4-8	A 00442	1/2	10	0.108	3.06
N4-10	A 01112	5/8	5	0.185	9.28
N4-12	A 04731	3/4	5	0.345	11.88

NUT - FLARE SEAL CAP



Unv Part	Part	Size	Box	Wt	List
N5-4	A 04544	1/4	50	0.030	0.61
N5-5	A 04758	5/16	25	0.027	2.19
N5-6	A 04545	3/8	25	0.050	1.17
N5-8	A 04546	1/2	25	0.069	1.38
N5-10	A 04560	5/8	10	0.137	2.19
N5-12	A 04951	3/4	10	0.221	6.22

TIGHTENING



Unv Part	Part	Size	Box	Wt	List
NFT5-4	A 16447	1/4	2000	0.015	0.82
NFT5-6	A 16448	3/8	1400	0.038	2.81

NUT - SHORT FORGED REDUCING



Unv Part	Part	Size	Box	Wt	List
NRS4-43	A 05132	1/4	10	0.027	3.75
NRS4-54	A 05247	5/16	10	0.055	7.67
NRS4-64	A 05140	3/8	25	0.060	1.69
NRS4-65	A 05282	3/8	10	0.027	5.98
NRS4-86	A 05141	1/2	15	0.094	2.98
NRS4-108	A 05228	5/8	15	0.125	3.25

NUT - SHORT FORGED



Unv Part	Part	Size	Box	Wt	List
NS4-3	A 05238	3/16	50	0.024	3.84
NS4-4	A 05051	1/4	50	0.035	1.13
NS4-5	A 05239	5/16	25	0.040	2.93
NS4-6	A 05052	3/8	25	0.052	1.51
NS4-8	A 05053	1/2	15	0.084	2.22
NS4-10	A 05157	5/8	10	0.120	3.16
NS4-12	A 05222	3/4	10	0.235	5.67

PLUG - FLARE



Unv Part	Part	Size	Box	Wt	List
P2-3	A 05045	3/16	15	0.016	1.22
P2-4	A 00121	1/4	25	0.022	0.82
P2-6	A 00122	3/8	25	0.059	1.33
P2-8	A 00123	1/2	25	0.095	6.58
P2-10	A 04536	5/8	15	0.137	6.58
P2-12	A 04757	3/4	10	0.225	6.58

PLUG - BRASS PIPE



Unv Part	Part	Size	Box	Wt	List
P3-A	A 00250	1/8	50	0.030	0.61
P3-B	A 00249	1/4	50	0.048	1.17
P3-C	A 00425	3/8	25	0.058	2.70
P3-D	A 04759	1/2	25	0.108	2.70
P3-E	A 05004	3/4	10	0.209	5.05

