



Instructions

Remove the guards from the box and inspect for damage. Secure the coil guards to the the unit covering the condenser coil using the included screw package. Each guard is numbered.



GUARD 1
NON SERVICE
SIDE





GUARD 2
SERVICE SIDE



130-DK-090-11

COIL GUARD FOR DAIKIN DRC/
G/H 7.5-10 TON and DFC/G/H
7.5-12.5 TON

281-987-8400 • 281-987-9494 (fax)
1318 Buschong, Houston, TX 77039
www.mcdanielmetals.com



GUARD 3
LEFT END



GUARD 4
RIGHT END